InstaShow® WDC15

Driver-Free 4K UHD Wireless Presentation System

Designed for huddle and small meeting rooms, WDC15 enables instant plug-and-play wireless presentations—no apps, drivers, or network setup required. Presenters—even guests—can access professional-grade presentations with a tap.





No App Download Required

Nosoftwareorapprequired—just plug in and instantly share content during your meeting.



No Driver Needed

No drivers needed—just plug in and share your screen instantly during meetings.

*SupportsWindows, macOS, Linux, orChromeOS systems.



No Network Setup Required

No complex network setup or IT help needed. Receiver and button pair automatically—just plug and play to start presenting instantly.





Specifications

InstaShow Receiver

Power Supply	2A, DC 5V±10%
Normal Power Consumption	10W (x1)
LAN (RJ45)	(x1)
HDMI Out	110x110x29 mm
Dimensions without Antenna	
Weight	205 g

InstaShow Package

Receiver Button	(x1) (x1) (x1)
Cradle	(x1)
Power Adapter	(x2), 2dbi, MIMO
Antenna HDMI	(x1)
Cable** Safety	(x1)
Statement	

InstaShow Button

Connector Type	USB Type-C (Default)**	
Function Key	Mode Key	
**Switchable between Type-C and HDMI.		

InstaShowCradle


Dimensions	84.5x62.5x128 mm
Weight	568 g

InstaShow Features

Video Outputs	HDMI 1.4 (with HDCP)
Maximum Output Resolution (Receiver)	Up to 4K 30Hz
WiFi Standard	5
Wireless Frequency	5G
Wireless Data Rate (Maximum)	AC1200 (5G 867 Mbps)
Simultaneous Connections	16
WiFi Protected Access	WPA3
Advanced Encryption Standard	AES128
Transmission Distance	15 m

Part Number: 9H.K0EBY.E0E EAN: 4718755096419

3 Steps for One-Time Wireless Presentation Setup



Set up once—no need to rebuild for every meeting.


Steps:

- 1. Connect display to Receiver via HDMI cable
- 2. Plug Button into presenter's laptop
 - ***Supports Windows, MacBook, or Chromebook systems.
- 3. Share content from presenter's laptop via Button






Dimensions & Connectivity





Receiver



29m



- 1. Present Key
- 2. USB-C Connector
- 3. Mode Key

- 4. Reset Button
- 5. Paring Key
- 6. Standby On/Off
- 7. USB for Touchback
- 8. RJ45
- 9. HDMI Out
- 10. USB C Power Port



benq.eu/en-eu/business/wireless-presentation/instashow-wireless-collaboration.html



